


#### **Presentation Contents**

- Speakers
- 2. Company Introduction
- 3. Product Qualification Program Guidance
- 4. Pre-Shipment Inspection Guidance
- 5. Batch Testing Guidance
- 6. Ongoing Reliability Monitoring Guidance
- 7. Q+A Session





# **Today's Speakers**

#### **Presenters**



**Tristan Erion-Lorico**VP of Sales and Marketing **Kiwa PVEL** 



Don Cowan
Director of Sales & Marketing
Kiwa PI Berlin



Mahyar Nezhad
Principal PV Module Consultant
Kiwa PI Berlin

#### **Moderator**




Max Macpherson
Senior Program Manager
Kiwa PVEL



#### Kiwa Overview


- Kiwa is a global testing, inspection and certification (TIC) company, founded in 1948.
- Headquartered in Rijswijk, the Netherlands with more than 10,000 employees, working in over 37 countries. Kiwa is primarily active in renewable energy, construction, manufacturing, fire safety, medical devices, food & water.
- Kiwa's solar businesses at a glance:



■ Kiwa's mission is to create trust by contributing to the transparency of the quality, safety and sustainability of products, services and organizations as well as of personal and environmental performance.



### Kiwa PVEL is the Independent Lab of the Downstream Solar Market



#### Services at a glance

- Extended reliability and performance testing for PV modules
- Batch testing of PV modules
- Outdoor testing at PVUSA, an iconic grid-connected research site
- Data services for PV buyers and investors

See more details at kiwa.com/pvel



Kiwa PI Berlin: Trusted Solar and Storage Advisors









#### 1,000+


Factory Audits Conducted across PV Modules, Inverters, BESS and Transformers

175+ GW

**PV Production Supervised** 

### 3 PV Labs in Key Markets

Berlin, Suzhou, California (PVEL)





### Managing Quality From Qualification to Production


The presented quality assurance tools are key elements of Kiwa's PV Module Procurement Best Practices: kiwa.com/modulebestpractices

#### Pre-production:

- Qualify the product
  - Includes Product Qualification Program (PQP) testing
- Set contractual requirements
- Audit the factory

#### Production:

- Verify production quality
- Includes Pre-Shipment Inspection (PSI), Batch Testing and Ongoing Reliability Monitoring (ORM)
- Validate quality onsite








### **PQP Test Sequence**

The PQP evolves every two years based on feedback from Kiwa PVEL's downstream partners, module manufacturers, and the industry's collective understanding of module failure modes and test mechanisms.

The most recent update introduced the new UVID test and streamlined many of the tests leading to faster execution of PQP projects.


Learn more about the current version of the PQP test plan at <a href="https://kiwa.com/pvel/pqp">kiwa.com/pvel/pqp</a>.





### **PQP** Result Trends

#### ■ Results have improved over time. For example:



see more trends at scorecard.pvel.com.

#### PQP results by test for the past two years:

TEST	<3%	3-5%	≥5%	OTHER FAILURES*
тс	95%	4%	1%	7%
DH	92%	6%	2%	8%
MSS	99%	1%	0%	6%
PID	83%	11%	6%	2%
UVID	25%	35%	22%	17%
TEST	<1%	1-2%	≥2%	OTHER FAILURES**
LID+LETID	84%	15%	1%	13%



### **PQP** Acceptance Guidance

TEST	ACCEPTANCE LEVEL	POWER DEGRADATION	OTHER CHARACTERISTICS
	Clear Pass:	<3%	No visual inspection majors, wet leakage failures or diode failures (for TC and MSS).
TC, DH, MSS, PID	Conditional Pass:	3-5%	Visual inspection majors, wet leakage failures and/or diode failures (for TC and MSS) with positive RCCA (e.g. no design/process flaws).
c	Clear Fail:	≥5%	Visual inspection majors, wet leakage failures and/or diode failures (for TC and MSS) with no or negative RCCA.
	Clear Pass:	<1%	No visual inspection majors or wet leakage failures.
LID plus LETID	Conditional Pass:	1-2%	Visual inspection majors and/or wet leakage failures with positive RCCA (e.g. no design proces flaws).
	Clear Fail:	≥2%	Visual inspection majors and/or wet leakage fallures with no or negative RCCA.

TEST	ACCEPTANCE LEVEL	POWER DEGRADATION	OTHER CHARACTERISTICS
HSS	Clear Pass:	Less applicable	No glass breakage, no other visual inspection majors or wet leakage failures.
HSS (hail size determined by project site's susceptibility to hail impacts)	Conditional Pass:		Visual inspection majors (other than glass breakage) and/or wet leakage failures.
	Clear Fail:		Glass breakage
	Clear Pass:		No visual inspection majors, delta b* ≤5
BDS	Conditional Pass:	Not applicable	Visual inspection majors (other than backsheet cracking) and/or delta b* >5
	Clear Fail:		Backsheet cracks

A conditional pass is based on the module manufacturer completing a detailed root cause corrective action (RCCA) analysis to the module buyer's satisfaction.






### **Pre-Shipment Inspections**


#### What are Pre-Shipment Inspections (PSI)?

- End of production line inspections and characterizations.
- Typically are "re-inspections" to verify the factory is meeting agreed-to inspection criteria.
- Rapid inspections on each batch prior to the modules leaving the factory.

#### **Key Aspects of PSI:**


- Visual Inspections
- Flash Testing
- Bifaciality Measurements
- Dimensional Verification
- Electroluminescence (EL) Imaging









### Pre-Shipment Inspections- What is Being Found?








### Pre-Shipment Inspections - Manufacturer Comparison






Defect rates across one manufacturer's factory locations.



# **Acceptable Quality Limits**

#### **AQL Analysis**

- Manufacturers commonly use ISO-2859-1 sampling standard, Acceptable Quality Limits (AQL).
- Kiwa PI Berlin performed an analysis comparing AQL values across 59 recent utility-scale projects involving 25 manufacturers.
- An AQL of 0 was applied for critical defects in 100% of the projects. Over 80% of the projects used an AQL of 0.65–1.5 for major defects and 2.5–4.0 for minor defects





#### **Sampling Size Guidelines**

- Batch based on ISO 2859-1: GI Level II
- Recommend batch size of 10 MW or one week of production, whichever is less.

#### **AQL Guidelines**

- 0 for critical defects
- 1.5 for major defects
- 4.0 for minor defects.

# Pre-Shipment Inspection - Guidelines

TEST	MINUMUM SAMPLE SIZE	DEFECT CATEGORY	MAXIMUM AQL
Visual Inspection,		Critical	0
Flash Testing, Bifaciality, Dimensional Verification, EL Imaging	ISO 2859.1 General Inspection Level II	Major	1.5
		Minor	4





### Potential Risks of BOM and Process Variations Beyond PQP Testing

Is PQP data alone enough to guarantee the BOM and process variations for a large project like a 200MW installation?

Project size (MW)	Module Power (W)	Number of modules
200	570	350877

PQP testing offers comprehensive data for module design/BOM qualification and benchmarking purposes. However, several factors can impact performance and reliability during mass production, including:

- Minor changes in lamination temperature
- Soldering time variations for the stringer
- Humidity variations in the curing room
- Small bubbles in the glass
- Inconsistencies in Cell batch quality
- Flectrical Connection Variations


To continuously monitor the process and materials during production and minimize risks, a comprehensive testing and monitoring program has been developed to evaluate PV modules at different stages of production and across various batch sizes.



### **Production Module Testing**

# What is Batch Testing and Ongoing Reliability Monitoring (ORM)?


- Evaluates PV modules at different stages of production.
- Stress tests for verifying material and process stability.
- Short and mid duration testing at various internals allows unseen issues affecting consistent quality and reliability.
- Validates buyer's produced supply matches performance contractual expectations.





- Batch Testing validates short-duration testing results.
- Performed at a third-party lab, or onsite lab.
- Includes LID, LETID, PID, and low-light performance tests to identify potential issues that are not detectable via production oversight/PSI.
- Mechanical load testing is included to minimize risks of onsite module breakage.
- Gel content and peel strength testing is performed on coupons.

### **Batch Testing Protocol**





- Batch Testing Criteria compliance is measured by power degradation variances, VI, or WL failures.
- Testing conformance is recommended for batch release.
- In case of any failures, Kiwa supports customers in analyzing the RCCA.

# **Batch Testing Criteria**

TEST	POWER DEGRADATION	OTHER CHARACTERIZATIONS
Flash testing	≥minimum power specified on datasheet and power label	N/A
Bifaciality	≥minimum bifaciality factor specified on datasheet and power label	N/A
LID, LETID	Power degradation ≤ 1%	No major visual defects or wet leakage failures.
PID, SDML	Power degradation ≤ 3%	No major visual defects or wet leakage failures.
Low light performance	Module performance ≥ the initial PAN file	N/A
Peel strength	> 60 N/cm at both interfaces	N/A
Gel content	Gel content > 75% for each measured point	N/A



### Ongoing Reliability Monitoring Protocol



- ORM is designed for the long-term evaluation of <u>consistent</u> performance and reliability of the modules.
- Testing mainly based on the IEC/UL 61215 standard.
- The ORM program includes a variety of tests tailored to the latest cell technologies and module designs including hail test and UVID.



# Ongoing Reliability Monitoring Criteria


TEST	POWER DEGRADATION	OTHER CHARACTERIZATIONS
TC200, DH1000, HF10, UVID60	Power degradation ≤3%	No major visual defects or wet leakage failures.
Hail test (hail size determined by project site's susceptibility to hail impacts)	Power degradation ≤ 3%	No glass breakage, no other major visual defects or wet leakage failures.
PAN/IAM	Module performance ≥ the initial PAN file	No major visual defects.

- Kiwa recommends performing ORM for every 50 MW or one month of production, whichever is less.
- Criteria compliance is measured by power degradation variances, glass breakage (hail), and WL failures.
- Similar to batch testing, in case of any failures, Kiwa supports customers in analyzing the RCCA.



#### Conclusion

- These guidelines are a part of Kiwa's holistic PV module procurement best practices.
- Product Qualification Program, Pre-Shipment Inspection, Batch Testing and Ongoing Reliability Monitoring provide a comprehensive testing framework for ensuring that PV modules meet the highest standards of quality and reliability.
- PV module quality should be evaluated from qualification to production.
- This set of testing and inspection guidance is intended to help raise the bar on module quality, resulting in higher performing PV projects across the industry.









#### **We Create Trust**

#### Visit us:

- kiwa.com/raising-the-bar
- kiwa.com/modulebestpractices
- kiwa.com/solar
- kiwa.com/pvel
- kiwa.com/pi-berlin

